

## PARCEL PRO BOX III

1. Place the Parcel Drop Box in the desired location
2. Mark 4 circles against the wall using the holes in the back of the Drop Box this is where the screws will go
3. Remove the box and drill into the wall where you have previously marked
4. Place the raw plugs that are provided into the holes that you drilled
5. Place the drop box in its original position
6. Fit the screws provided into the raw plugs so that the Parcel Drop Box is held in place
7. Your Parcel Drop Box is now ready for use



**OFFICE FURNITURE**  
**DIRECT2U** →